

# UNDERSTANDING THE GPIO PINS

Connecting electronic components to the Pi is done via one or more of the pins in the so-called header. The number of pins has "grown" between the different Raspberry Pi board versions, but all recent ones have a 40-pin header. It's of course important to be aware of the correct numbering to not correct components the wrong way.



## Type of pins

The pins have different uses

#### Power and ground

Both 5V and 3.3V are available as power pins and, of course, also ground pins. Anytime the board is powered you have a fixed power supply available for your components. You have to take into account not to connect devices that need a lot of current, otherwise the Raspberry Pi itself will not behave as expected and reboot for instance.

### Digital GPIO

The other ones are "General-Purpose Input/Output" (GPIO) pins. These pins can be addressed with software to act as input or output for an application. They use 3.3V,

meaning an output pin will be set to 0V (low) or 3.3V (high) and an input pin will read 0V as low and 3.3V as high.

Most of the GPIOs have an internal pull-up or pull-down resistor which can be enabled in software.

#### Overview

The following image gives you an overview of the pins and types of a typical 40-pin header. Note the different numbers being used:

- 1. PIN: 1 to 40 logical order of the pin
- 2. **BCM**: the number to be used in your Java code to specify the GPIO to be used. BCM refers to the "Broadcom SOC channel" number, which is the numbering inside the chip which is used on the Raspberry Pi. These numbers changed between board versions as you can see in the previous tables for the 26-pin header type 1 versus 2, and or not sequential.
- 3. **WPI**: WiringPi number which was used by V.1 of Pi4J. The WiringPi numbering has a "historical reason". When development for the very first Raspberry Pi's was ongoing, only 8 pin-numbers were foreseen. But, when the designs further evolved and more pins were added, the numbering in WiringPi was extended to be able to address the extra pins.

**Board PIN** 

	Doan	UFIN	
3.3 VDC	PIN 1	PIN 2 5.0 VDC	
2 8 SDA1 (I2C)	PIN 3	PIN 4 5.0 VDC	
3 9 <b>SCL1 (12C)</b>	5 PIN	6 Ground	
4 7 GPCLKO	PIN 7	PIN 8 UART TxD WPI 15	
Ground	9	PIN 10 UART RXD 16	
BCM WPI 17 0	PIN 11	PIN PCM_CLK/PWM0 1	всм 18
BCM WPI 27 2	PIN 13	PIN Ground	
BCM WPI 22 3	PIN 15	PIN WPI 16 4	всм 23
3.3 VDC	PIN 17	PIN WPI 18 5	всм 24
10 12 MOSI (SPI)	PIN 19	PIN Ground	
9 13 MISO (SPI)	PIN 21	PIN WPI 22 6	всм 25
11 14 SCLK (SPI)	PIN 23	PIN 24 CEO (SPI) WPI 10	всм 8
Ground	PIN 25	PIN 26 CE1 (SPI) WPI 11	всм 7
0 30 SDA0 12C ID EEPROM	PIN 27	PIN 28 SCLO 12C ID EEPROM 31	всм 1
5 21 GPCLK1	PIN 29	PIN Ground	
6 22 GPCL2	9IN 31	PIN 26 PWM0 26	всм 12
13 23 <b>PWM1</b>	PIN 33	PIN Ground	
19 24 PCM_FS/PWM1	PIN 35	PIN WPI 36 27	
всм wpi 26 25	9IN 37	PIN 38 PCM_DIN 28	всм 20
Ground	9IN 39	PEN 40 PCM_DOUT 29	
		· · · · · · · · · · · · · · · · · · ·	

Power
Ground
Digital
Digital and PWM
Digital without pulldown